




FIG. 3



**FIG. 6**

30

32R 32S 33R 31R 31S 31S 31L 32S 33L 32L

34R BATTERY 36R INVERTER R 35R DRIVER R 39 FUNCTION GENERATOR 40 PERSONAL COMPUTER 38 CONTROL ON/OFF SWITCH 37

34L BATTERY 36L INVERTER L 35L DRIVER L 38

SENSOR SIGNAL PATH  
CONTROL SIGNAL PATH  
MOTOR DRIVE CURRENT PATH